








# Pop-Up Cinema Series

## Indoor/Outdoor Portable Pop-up Projection Screen User's Guide

Thank you for choosing the *Pop-Up Cinema* portable projection screen! Please read through this user guide before utilizing the screen. Correct usage and maintenance will ensure a long product life.


### Parts List

A. Carrying Bag x1 	B. Screen x1 	C. Net Base x1 	D. Support Bar x2 	E. Stake x4 
---	--	---	---	--


Note: The parts list above is subject to change without notice.

### Installation Set-Up:


1) Take out the screen and net base from the carrying bag and expand them.




2) Connect the Screen to the net base.



3) Insert the support bar behind the screen and then connect the rod sections so that it is at maximum length.




4) Ground the net base with the stakes.




### Disassembling the screen


1) Step on the back end of the screen and bring middle part of screen or net base towards you approximately 12" from your foot and hold that down stepping on it with your other foot.



2) While holding the material down with both feet, lean forward and grab the left and right side.




3) Bring the right side in toward your left foot and bring the left side towards your right foot.




4) With your feet in position, bring both left and right sides in towards the ground.



5) Continue to bring the material down and remove your left foot. Push the screen down and continue to hold it in the compressed position. You should now be able to insert it into the bag.



6) Repeat the above process with the net base to ensure it will also fit in the carrying bag.



If a visual demonstration is needed, please view our disassembly video at:

[www.elitescreens.com/video/popc-disassemble](http://www.elitescreens.com/video/popc-disassemble)